

**JENSEN**<sup>®</sup>  
audio

**MODEL SMPS-125**

**PORTABLE STEREO SPEAKER SYSTEM**

**USER MANUAL**



Please read this User Manual carefully before using the unit and retain the Manual for future reference



## WARNING

- Do not throw the product into fire to avoid danger of explosion.
- No compensation responsibility for malfunctions caused by improper use.
- Do not attempt to disassemble or alter any part of the unit that is not expressly described in this guide. Internal inspections, alternations and repairs should be conducted by qualified service personnel.

## IMPORTANT SAFETY INSTRUCTIONS

1. The apparatus and AC/DC adaptor shall not be exposed to dripping and splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus and AC/DC adaptor.
2. The mains plug of the AC/DC adapter is used as the disconnect device. The power adaptor should always remain readily operable and should not be obstructed OR should be easily accessed during intended use.
3. To completely disconnect the apparatus from supply mains, the mains plug of the AC/DC adapter shall be disconnected from the mains socket outlet completely.
4. Minimum distances of 4 inches (10cm) around the apparatus and AC/DC adapter shall be available for sufficient ventilation.
5. The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-clothes, curtains, etc. ;  
No naked flame sources such as lighted candles should be placed on the apparatus.
6. Attention should be drawn to environmental aspects of battery disposal.
7. The apparatus and AC/DC adapter should be used in moderate climates.
8. The rating plate of the apparatus is located on its bottom enclosure.
9. Battery (battery pack or battery installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

**CAUTION FOR LITHIUM BATTERY:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.



## PROTECT YOUR FURNITURE!!


This system is equipped with non-skid rubber 'feet' to prevent the product from moving when you operate the controls. These 'feet' are made from non-migrating rubber material specially formulated to avoid leaving any marks or stains on your furniture. However certain types of oil based furniture polishes, wood preservatives, or cleaning sprays may cause the rubber 'feet' to soften, and leave marks or a rubber residue on the furniture.

To prevent any damage to your furniture we strongly recommend that you purchase small self-adhesive felt pads, available at hardware stores and home improvement centers everywhere, and apply these pads to the bottom of the rubber 'feet' before you place the product on fine wooden furniture.

## POWER SOURCES

The SMPS-125 can be operated by either battery or AC power (Batteries and AC adaptor are not included).

**AC adaptor** Input: 120V~ 60Hz  
Output: 6 V  400 mA 

**Batteries** 4 x 1.5V  'AAA' (UM-4)

If batteries are installed and the AC adaptor is plugged in, the SMPS-125 will automatically switch to AC power to conserve battery power.

## POWER INSTALLATION

1. For AC power (AC Adaptor not included), insert the AC adaptor plug into the DC Jack on the back of the SMPS-125.
2. For DC power, remove the battery compartment cover on the bottom of the cabinet and insert 4 x 'AAA' (UM-4) batteries (not included) into the battery compartment. Make sure to observe the correct polarity markings when installing the batteries. Replace the battery compartment cover when finished.


**IMPORTANT:** Make sure that the batteries are installed correctly. Wrong polarity may damage the unit and void the Warranty.

## BATTERY CARE


1. Do not mix old and new batteries.
2. Do not mix alkaline, standard or rechargeable batteries.
3. Only batteries of the same or equivalent type as recommend are to be used.
4. If the unit is not to be used for an extended period of time, remove the battery.
5. Do not dispose of batteries in fire, batteries may explode or leak.
6. Replace the batteries when the unit stops operating properly.
7. Remove exhausted batteries from the unit, dispose promptly and properly.

## PRODUCT OVERVIEW


### Top View



### Bottom View



### Rear View



## **OPERATION GUIDE**


This Speaker System is equipped with 2 Auxiliary (AUX-IN) Inputs:

A fold-down 3.5mm plug is located in the 0.6" well that runs across the length of the unit and a second 3.5mm plug and cord is located in the battery compartment. You can use either one for playing.

1. Fully insert the AUX Input plug from the bottom cabinet of the Speaker System into the Headphone Jack of your external audio player (MP3 player, iPod®, iPhone™ iPad) or



2. Lift up the 3.5 mm plug located in the well and connect it to the Headphone Jack of your iPod or other digital audio player if applicable.



3. Slide the POWER SWITCH to the "ON" position. The Power Indicator will light.
4. Turn on the external audio player that you plan to connect to this Speaker System and set the volume level to a low setting.
5. Follow the iPod/iPhone/iPad operation instructions to operate your iPod/iPhone/iPad.
6. Gradually adjust both the output of the attached player and the Speaker System until the desired volume level is reached.

7. Unplug the external device and turn off the Speaker System by sliding the POWER SWITCH to the “OFF” position when finish listening.

## CARE AND MAINTENANCE

- Place the product far away from heat sources, and protect the product from direct sunlight.
- Do not use the product where electric appliances are prohibited.
- Protect the product from violent impact and vibrations.
- If the cabinet becomes dusty, wipe the exterior with a soft dust cloth only. Never use dusting sprays or polishes on the cabinet.
- If the cabinet becomes dirty or smudged with fingerprints it may be wiped with a soft cloth that has been slightly dampened with a mild soap and water solution.

## TROUBLESHOOTING GUIDE

Should you experience difficulties in the use of this unit please refer to the following chart or call **1 800 777 5331** for Customer Service and Support.

Problems	Possible Solutions
Unit does not turn on after switching on the power switch.	<ol style="list-style-type: none"> <li>1. Make sure the batteries are inserted properly with the correct polarity as marked inside the compartment.</li> <li>2. The batteries may be exhausted. Please change all batteries at the same time.</li> </ol>
No sound coming from the Speaker	<ol style="list-style-type: none"> <li>1. Make sure the volume on the attached player is not set to zero and also check the connection between the audio input jack and the external player.</li> <li>2. Song files on your player may be corrupted. Please download from your computer again.</li> <li>3. External player (MP3, iPod or iPhone) is not on.</li> <li>4. Check and make sure the audio input cord is not damaged.</li> </ol>
Sound is distorted.	<ol style="list-style-type: none"> <li>1. Decrease the volume of the external player.</li> <li>2. Sound source from your player is distorted. Please download from your computer again.</li> </ol>



At Spectra, environmental and social responsibility is a core value of our business. We are dedicated to continuous implementation of responsible initiatives with an aim to conserve and maintain the environment through responsible recycling.

Please visit us at <http://www.spectraintl.com/green.htm> for more information on Spectra's green initiatives or to find a recycler in your area.

**90 DAY LIMITED WARRANTY AND SERVICE  
VALID IN THE U.S.A ONLY**

SPECTRA MERCHANDISING INTERNATIONAL, INC. warrants this unit to be free from defective materials or factory workmanship for a period of 90 days from the date of original customer purchase and provided the product is utilized within the U.S.A. This warranty is not assignable or transferable. Our obligation under this warranty is the repair or replacement of the defective unit or any part thereof, except batteries, when it is returned to the SPECTRA Service Department, accompanied by proof of the date of original consumer purchase, such as a duplicate copy of a sales receipt.

You must pay all shipping charges required to ship the product to SPECTRA for warranty service. If the product is repaired or replaced under warranty, the return charges will be at SPECTRA's expense. There are no other express warranties other than those stated herein.

This warranty is valid only in accordance with the conditions set forth below:

1. The warranty applies to the SPECTRA product only while:
  - a. It remains in the possession of the original purchaser and proof of purchase is demonstrated.
  - b. It has not been subjected to accident, misuse, abuse, improper service, usage outside the descriptions and warnings covered within the user manual or non-SPECTRA approved modifications.
  - c. Claims are made within the warranty period.
2. This warranty does not cover damage or equipment failure caused by electrical wiring not in compliance with electrical codes or SPECTRA user manual specifications, or failure to provide reasonable care and necessary maintenance as outlined in the user manual.
3. Warranty of all SPECTRA products applies to residential use only and is void when products are used in a nonresidential environment or installed outside the United States.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. TO OBTAIN SERVICE please remove all batteries (if any) and pack the unit carefully and send it freight prepaid to SPECTRA at the address shown below. IF THE UNIT IS RETURNED WITHIN THE WARRANTY PERIOD shown above, please include a proof of purchase (dated cash register receipt) so that we may establish your eligibility for warranty service and repair of the unit without cost. Also include a note with a description explaining how the unit is defective. A customer service representative may need to contact you regarding the status of your repair, so please include your name, address, phone number and email address to expedite the process.

IF THE UNIT IS OUTSIDE THE WARRANTY PERIOD please include a check for **\$5.00** to cover the cost of repair, handling and return postage. All out of warranty returns must be sent prepaid.

It is recommended that you contact SPECTRA first at 1-800-777-5331 or by email at [custserv@spectraintl.com](mailto:custserv@spectraintl.com) for updated information on the unit requiring service. In some cases the model you have may be discontinued, and SPECTRA reserves the right to offer alternative options for repair or replacement.

SPECTRA MERCHANDISING INTERNATIONAL, INC.  
4230 North Normandy Avenue,  
Chicago, IL60634, USA.  
1-800-777-5331

To register your product, visit the link on the website below to enter your information.  
<http://www.spectraintl.com/wform.htm>

Printed in China